




Neoprene Can Holder



1. Cut out the template provided. Find a flat piece of neoprene and draw around the template.
2. Using sharp scissors or a cutting blade. Cut the can cooler shape out of the neoprene. Making sure to cut straight and with a neat edge.
3. With the shape now cut out. Apply a small amount of neoprene adhesive along the edge of *1a* and *1b*. Wait a few moments for the glue to dry slightly before carefully attaching both edges. Pressing firmly as you go.
(Tip: start of by lining up the top or bottom first. Then work your way along the edge till its full joined.)
4. Now repeat step 3 but for edges *2a* and *2b*.
5. After you glued all edges together it's best to leave overnight for the glue to set before use.

(For a custom cooler, just make edges 1 & 2 whatever height you want to suit a bigger can or even a glass bottle. Find out your new diameter and make that edge 3a & 3b.)

